


*Installation
Manual*

RS-232 SPECIFICATION



**How to properly create an RS-232 connection between
a PC and most SmartAVI RS-232 compliant devices**

How to properly create an RS-232 connection between a PC and most SmartAVI RS-232 compliant devices

Establish a connection to your RS-232 compliant device:

1. Connect a straight through male to female RS-232 cable (shown on right) to the RS-232 connector on the PC.
2. Connect the other end of the cable to the RS-232 compliant device.
3. Power on the device.



Male to Female Straight Cable (not provided)



Hyperterminal Settings

Setting up the Terminal application:

1. Open Hyperterminal on the PC. (or use the terminal client of your choice)
2. Use the default settings to create a connection to the device (see settings on left). Settings **MUST** match those shown on the lower right.
3. Be sure that Flow Control is **None**.
4. The output of the device will be the same as the PC.

How to properly test an RS-232 connection between a PC and most SmartAVI RS-232 compliant devices

After you have established a connection to your device use the following commands:

1) To set a video crosspoint:

//FxxMyyIzz<CHK><CR>

e.g. to set video input 3 to output 12 on a router with frame address "0"
send the command: **//F00M12I03<0x42><CR>**

2) To set RS-232 crosspoint:

//FxxRyyIzz<CHK><CR>

3) To disconnect RS-232 crosspoint:

//FxxDyyIzz<CHK><CR>

4) To set new frame address:

//FxxFnn<CHK><CR>

IMPORTANT

CALCULATING THE <CHK>

<CHK> stands for CHECKSUM: the <CHK> value is calculated by performing an XOR of the full command string. For example: //F00M12I03 will XOR to the hexadecimal value 0x42, therefore the value of <CHK> is 0x42.

How to properly test an RS-232 connection between a PC and most SmartAVI RS-232 compliant devices

RS-232 Commands continued:

5) To query crosspoints from PC:

//FxxU<CHK><CR>

- If all outputs are connected to input 1 then a 4x4 Matrix will respond with **<0x80><0x80><0x80><0x80><CR>**
- The router will send back one byte for each output and the string ends with a **<CR>**. The first byte sent is Output #1. In the example above, since there are 5 bytes total, we know that there are 4 outputs.
- To calculate the input number, the router sends the input number with the 7th bit set.
 - 0x80 = "1000 0000" → input 0
 - 0x81 = "1000 0001" → input 1
 - ...
 - 0x8F "1000 1111" → input 15

Comms Port Settings:

Baud Rate	9600
Start Bits	1
Data Bits	8
Parity	None
Stop Bits	1

Notes:

- When successful, commands #1-4 will acknowledge by sending the checksum with nibbles swapped & **<CR><LF>**
 - e.g. checksum of 0x24 acknowledges with **<0x42><CR><LF>**

How to properly test an RS-232 connection between a PC and most SmartAVI RS-232 compliant devices

The following are example commands for the first 8 inputs and 8 outputs. The hexadecimal values of the commands are also listed.

<i>Operation</i>	<i>Command</i>	<i>Hexidecimal Value</i>
input_1_output_1	// F 0 0 M 0 1 1 0 1 <CHK> <CR>	2F 2F 46 30 30 4D 30 31 49 30 31 42 0D
input_2_output_1	// F 0 0 M 0 1 1 0 2 <CHK> <CR>	2F 2F 46 30 30 4D 30 31 49 30 32 41 0D
input_3_output_1	// F 0 0 M 0 1 1 0 3 <CHK> <CR>	2F 2F 46 30 30 4D 30 31 49 30 33 40 0D
input_4_output_1	// F 0 0 M 0 1 1 0 4 <CHK> <CR>	2F 2F 46 30 30 4D 30 31 49 30 34 47 0D
input_5_output_1	// F 0 0 M 0 1 1 0 5 <CHK> <CR>	2F 2F 46 30 30 4D 30 31 49 30 35 46 0D
input_6_output_1	// F 0 0 M 0 1 1 0 6 <CHK> <CR>	2F 2F 46 30 30 4D 30 31 49 30 36 45 0D
input_7_output_1	// F 0 0 M 0 1 1 0 7 <CHK> <CR>	2F 2F 46 30 30 4D 30 31 49 30 37 44 0D
input_8_output_1	// F 0 0 M 0 1 1 0 8 <CHK> <CR>	2F 2F 46 30 30 4D 30 31 49 30 38 4B 0D
input_1_output_2	// F 0 0 M 0 2 1 0 1 <CHK> <CR>	2F 2F 46 30 30 4D 30 32 49 30 31 41 0D
input_2_output_2	// F 0 0 M 0 2 1 0 2 <CHK> <CR>	2F 2F 46 30 30 4D 30 32 49 30 32 42 0D
input_3_output_2	// F 0 0 M 0 2 1 0 3 <CHK> <CR>	2F 2F 46 30 30 4D 30 32 49 30 33 43 0D
input_4_output_2	// F 0 0 M 0 2 1 0 4 <CHK> <CR>	2F 2F 46 30 30 4D 30 32 49 30 34 44 0D
input_5_output_2	// F 0 0 M 0 2 1 0 5 <CHK> <CR>	2F 2F 46 30 30 4D 30 32 49 30 35 45 0D
input_6_output_2	// F 0 0 M 0 2 1 0 6 <CHK> <CR>	2F 2F 46 30 30 4D 30 32 49 30 36 46 0D
input_7_output_2	// F 0 0 M 0 2 1 0 7 <CHK> <CR>	2F 2F 46 30 30 4D 30 32 49 30 37 47 0D
input_8_output_2	// F 0 0 M 0 2 1 0 8 <CHK> <CR>	2F 2F 46 30 30 4D 30 32 49 30 38 48 0D
input_1_output_3	// F 0 0 M 0 3 1 0 1 <CHK> <CR>	2F 2F 46 30 30 4D 30 33 49 30 31 40 0D
input_2_output_3	// F 0 0 M 0 3 1 0 2 <CHK> <CR>	2F 2F 46 30 30 4D 30 33 49 30 32 43 0D
input_3_output_3	// F 0 0 M 0 3 1 0 3 <CHK> <CR>	2F 2F 46 30 30 4D 30 33 49 30 33 42 0D
input_4_output_3	// F 0 0 M 0 3 1 0 4 <CHK> <CR>	2F 2F 46 30 30 4D 30 33 49 30 34 45 0D
input_5_output_3	// F 0 0 M 0 3 1 0 5 <CHK> <CR>	2F 2F 46 30 30 4D 30 33 49 30 35 44 0D
input_6_output_3	// F 0 0 M 0 3 1 0 6 <CHK> <CR>	2F 2F 46 30 30 4D 30 33 49 30 36 47 0D
input_7_output_3	// F 0 0 M 0 3 1 0 7 <CHK> <CR>	2F 2F 46 30 30 4D 30 33 49 30 37 46 0D
input_8_output_3	// F 0 0 M 0 3 1 0 8 <CHK> <CR>	2F 2F 46 30 30 4D 30 33 49 30 38 49 0D
input_1_output_4	// F 0 0 M 0 4 1 0 1 <CHK> <CR>	2F 2F 46 30 30 4D 30 34 49 30 31 47 0D
input_2_output_4	// F 0 0 M 0 4 1 0 2 <CHK> <CR>	2F 2F 46 30 30 4D 30 34 49 30 32 44 0D
input_3_output_4	// F 0 0 M 0 4 1 0 3 <CHK> <CR>	2F 2F 46 30 30 4D 30 34 49 30 33 45 0D
input_4_output_4	// F 0 0 M 0 4 1 0 4 <CHK> <CR>	2F 2F 46 30 30 4D 30 34 49 30 34 42 0D
input_5_output_4	// F 0 0 M 0 4 1 0 5 <CHK> <CR>	2F 2F 46 30 30 4D 30 34 49 30 35 43 0D
input_6_output_4	// F 0 0 M 0 4 1 0 6 <CHK> <CR>	2F 2F 46 30 30 4D 30 34 49 30 36 40 0D
input_7_output_4	// F 0 0 M 0 4 1 0 7 <CHK> <CR>	2F 2F 46 30 30 4D 30 34 49 30 37 41 0D
input_8_output_4	// F 0 0 M 0 4 1 0 8 <CHK> <CR>	2F 2F 46 30 30 4D 30 34 49 30 38 4E 0D
input_1_output_5	// F 0 0 M 0 5 1 0 1 <CHK> <CR>	2F 2F 46 30 30 4D 30 35 49 30 31 46 0D
input_2_output_5	// F 0 0 M 0 5 1 0 2 <CHK> <CR>	2F 2F 46 30 30 4D 30 35 49 30 32 45 0D
input_3_output_5	// F 0 0 M 0 5 1 0 3 <CHK> <CR>	2F 2F 46 30 30 4D 30 35 49 30 33 44 0D
input_4_output_5	// F 0 0 M 0 5 1 0 4 <CHK> <CR>	2F 2F 46 30 30 4D 30 35 49 30 34 43 0D
input_5_output_5	// F 0 0 M 0 5 1 0 5 <CHK> <CR>	2F 2F 46 30 30 4D 30 35 49 30 35 42 0D
input_6_output_5	// F 0 0 M 0 5 1 0 6 <CHK> <CR>	2F 2F 46 30 30 4D 30 35 49 30 36 41 0D
input_7_output_5	// F 0 0 M 0 5 1 0 7 <CHK> <CR>	2F 2F 46 30 30 4D 30 35 49 30 37 40 0D
input_8_output_5	// F 0 0 M 0 5 1 0 8 <CHK> <CR>	2F 2F 46 30 30 4D 30 35 49 30 38 4F 0D

How to properly test an RS-232 connection between a PC and most SmartAVI RS-232 compliant devices



```

input_1_output_6 //F00M06101 <CHK> <CR> 2F 2F 46 30 30 4D 30 36 49 30 31 45 0D
input_2_output_6 //F00M06102 <CHK> <CR> 2F 2F 46 30 30 4D 30 36 49 30 32 46 0D
input_3_output_6 //F00M06103 <CHK> <CR> 2F 2F 46 30 30 4D 30 36 49 30 33 47 0D
input_4_output_6 //F00M06104 <CHK> <CR> 2F 2F 46 30 30 4D 30 36 49 30 34 40 0D
input_5_output_6 //F00M06105 <CHK> <CR> 2F 2F 46 30 30 4D 30 36 49 30 35 41 0D
input_6_output_6 //F00M06106 <CHK> <CR> 2F 2F 46 30 30 4D 30 36 49 30 36 42 0D
input_7_output_6 //F00M06107 <CHK> <CR> 2F 2F 46 30 30 4D 30 36 49 30 37 43 0D
input_8_output_6 //F00M06108 <CHK> <CR> 2F 2F 46 30 30 4D 30 36 49 30 38 4F 0D
input_1_output_7 //F00M07101 <CHK> <CR> 2F 2F 46 30 30 4D 30 37 49 30 31 44 0D
input_2_output_7 //F00M07102 <CHK> <CR> 2F 2F 46 30 30 4D 30 37 49 30 32 47 0D
input_3_output_7 //F00M07103 <CHK> <CR> 2F 2F 46 30 30 4D 30 37 49 30 33 46 0D
input_4_output_7 //F00M07104 <CHK> <CR> 2F 2F 46 30 30 4D 30 37 49 30 34 41 0D
input_5_output_7 //F00M07105 <CHK> <CR> 2F 2F 46 30 30 4D 30 37 49 30 35 40 0D
input_6_output_7 //F00M07106 <CHK> <CR> 2F 2F 46 30 30 4D 30 37 49 30 36 43 0D
input_7_output_7 //F00M07107 <CHK> <CR> 2F 2F 46 30 30 4D 30 37 49 30 37 42 0D
input_8_output_7 //F00M07108 <CHK> <CR> 2F 2F 46 30 30 4D 30 37 49 30 38 40 0D
input_1_output_8 //F00M08101 <CHK> <CR> 2F 2F 46 30 30 4D 30 38 49 30 31 4B 0D
input_2_output_8 //F00M08102 <CHK> <CR> 2F 2F 46 30 30 4D 30 38 49 30 32 48 0D
input_3_output_8 //F00M08103 <CHK> <CR> 2F 2F 46 30 30 4D 30 38 49 30 33 49 0D
input_4_output_8 //F00M08104 <CHK> <CR> 2F 2F 46 30 30 4D 30 38 49 30 34 4E 0D
input_5_output_8 //F00M08105 <CHK> <CR> 2F 2F 46 30 30 4D 30 38 49 30 35 4F 0D
input_6_output_8 //F00M08106 <CHK> <CR> 2F 2F 46 30 30 4D 30 38 49 30 36 4C 0D
input_7_output_8 //F00M08107 <CHK> <CR> 2F 2F 46 30 30 4D 30 38 49 30 37 4D 0D
input_8_output_8 //F00M08108 <CHK> <CR> 2F 2F 46 30 30 4D 30 38 49 30 38 42 0D
Query Current Matrix //F00U <CHK> <CR> 2F 2F 46 30 30 55 13 0D

```

How to properly test an RS-232 connection between a PC and most SmartAVI RS-232 compliant devices

RS-232 SPECIFICATIONS

CONNECTOR	PIN	NAME	DESCRIPTION
DB9 MALE - RECEIVE 	2	RxD	Receive Data on DB9 Male
	3	TxD	Transmit Data on DB9 Male
	5	SGND	Ground
DB9 FEMALE - TRANSMIT 	2	TxD	Transmit Data on DB9 Female
	3	RxD	Receive Data on DB9 Female
	5	SGND	Ground



NOTICE

The information contained in this document is subject to change without notice. Smart-AVI makes no warranty of any kind with regard to this material, including but not limited to, implied warranties of merchantability and fitness for any particular purpose. Smart-AVI will not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material. No part of this document may be photocopied, reproduced or translated into another language without prior written consent from Smart-AVI. For more information, visit www.smartavi.com.

SmartAVI, Inc. / Twitter: smartavi
11651 Vanowen St. North Hollywood, CA 91605
Tel: (818) 503-6200 Fax: (818) 503-6208
<http://www.SmartAVI.com>