




Instructional Guide

Accessing Task Manager via Web Interface

www.smartavi.com

In this tutorial, you will be walked through the steps of how to access the SignagePro Task Manager via Web Interface. SignagePro Web Interface will allow the user to access the SignagePro Task Manager from a computer (that is on the same network as the computer that has the SignagePro Manager and Server installed), without having the actual software installed on their computer.



Initial Steps

1. With the SignagePro Manager and Server installed on a computer (Server PC) in your network, open the command prompt of the Server PC and type: **ipconfig** to determine the IP Address of the Server. **(Figure 1.1)**

```
C:\Windows\system32\cmd.exe
C:\Users>ipconfig

Windows IP Configuration

Ethernet adapter Local Area Connection:

    Connection-specific DNS Suffix  . : Trendnet
    Link-local IPv6 Address . . . . . : fe80::2557:17b7:79c6:4551%11
    IPv4 Address. . . . .             : 192.168.10.3
    Subnet Mask . . . . .            : 255.255.255.0
    Default Gateway . . . . .        : 192.168.10.1
```

Figure 1.1

The IP address on the above example is '192.168.10.3'. This address is needed to access the Web Interface of the SignagePro.

Once you have received the proper IP Address of the Server PC, you can now access the Task Manager the SignagePro Manager through a different computer on the network (User PC).

2. At the User PC, open a web browser and type in the IP Address of the Server PC followed by '8888'. For the above IP Address, you would type: <http://192.168.10.3:8888> (Figure 1.2)




Figure 1.2

3. Now you should be at the login page of the SignagePro Web Interface. Type in your username and password login and press Enter. (**Figure 1.3**)




Figure 1.3

4. After logging in with your username and password, you should now be at the Task Manager page. From here, you should now be able to monitor and create tasks/schedules as you would in the Server PC's SignagePro Manager. (**Figure 1.4**)

SignagePro Task Manager - Windows Internet Explorer

http://192.168.10.3:8888/task_manager.php?reload

SignagePro Task Manager

SIGNAGEPRO WEB INTERFACE

Smart-AVI

Task Manager Station Manager User Manager Template Manager Help Log Out

Add Schedule Add Super Schedule Add New Task

▼ Default

▼ Schedules

| Actions | Schedule Name | Status | Enabled | Type | Tasks | ViewID | Stations | Days of Week | Days of Month | Month | Years | Time | Period | Interval |
|---------|---------------|---------|---------|--------------|-------|-----------|----------|--------------|---------------|-------|-------|----------|----------|----------|
| | Schedule 1 | Stopped | Yes | Periodically | 1 | Don't set | ALL | ALL | --- | ALL | --- | 11:34:00 | 00:00:00 | - |
| | Schedule 2 | Stopped | No | Periodically | 1 | Don't set | ALL | ALL | --- | ALL | --- | 11:34:00 | 00:00:00 | - |
| | Schedule 3 | Stopped | No | Periodically | 1 | Don't set | ALL | ALL | --- | ALL | --- | 11:34:00 | 00:00:00 | - |

▼ Tasks

| Actions | Task Name | Type | Command | Start Folder | Comment | Duration | Restart |
|---------|-----------|-------|--------------------------------|--------------|---------|----------|----------|
| | Task 1 | Image | G:\Media Files\Images\logo.png | - | --- | 00:00:00 | run next |
| | Task 2 | Image | G:\Media Files\Images\logo.png | - | --- | 00:00:00 | run next |
| | Task 3 | Image | G:\Media Files\Images\logo.png | - | --- | 00:00:00 | run next |

Copyright © 2010 Smart-AVI, Inc, All Rights Reserved.

Figure 1.4